
PPR 180-11
PPR 240-11
PPR 370-11
PPR 380-11

AH3 - AS3 / AST3 / AH4 - AS4 / AST4




Original Instructions -
Warning! Read instructions before using the machine.
Warnhinweis:
Lesen Sie vor Gebrauch der Maschine das Handbuch.
Attention :
Lisez la notice avant d'utiliser la machine.
Waarschuwing:
Lees deze instructies voor u de machine gebruikt
Instruções originais
Advertência! Leia as instruções antes de usar a máquina
Istruzioni originali
Avvertenza! Leggere le istruzioni prima di utilizzare l'apparecchio
Instrucciones originales
¡Atención! Lea las instrucciones antes de utilizar la máquina


Numatic INTERNATIONAL

www.numatic.com


Kit AH3 / AS3




Kit AST3



Kit AH4 / AS4




Kit AST4



Assembly - Zusammenbau - Assemblage - Samenstelling - Conjunto - Montaggio - Ensamblaje





Assembly - Zusammenbau - Assemblage - Samenstelling - Conjunto - Montaggio - Ensamblaje





Using your machine - Arbeiten mit dem Gerät - Utilisation de la machine - De machine gebruiken - Utilização da máquina - Uso dell'apparecchio - Utilización de la máquina


Start	Power On Indicator Light
Netzschalter	Netz-Kontrollanzeige
Démarrage	Voyant "sous tension
Start	Spanning indicator lampje
Ligar	Light
Avvio	Light
Encender	Light
















Cleaning - Staubfilterwechsel - Nettoyage - Reiniging - Limpeza - Pulizia Apparecchio - Limpieza


















Fitting the Face - Aufstecken des Gesichts - Montage du visage - Het gezicht aanbrengen






Removing the Face - Entfernen des Gesichts - Démontage du visage - Het gezicht verwijderen







PPR Plugged Cable





Wand docking, Parkfunktion, Système parcking, Parkeerstand - Suporte do tubo - Inserzione asta - Enganche de la tubería







Tool tidy PPR 240-11 only







Schematic Diagram - Schaltplan - Schéma électrique - Bedradingsschema - Diagrama esquemático - Schema apparecchio - Esquema eléctrico



Replacement parts - Ersatzteile - Pièces Détachées - Reserve Onderdelen - Peças de substituição - Ricambi - Repuestos

TriTex Primärfilter	
604165	TriTex-Filter
Filterbeutel	
604015	NVM 1CH (Pack of 10) (240)
604016	NVM 2BH (Pack of 10) (370/380)

1. Voltage
2. Frequency
3. Rated Input Power
4. Weight (ready to work)
5. Company Name & Address
6. Model
7. Machine yr/wk Serial number
8. WEEE Logo
9. Protection Class 2 Symbol
10. CE Mark

Rating Label



PPE (personal protective equipment) That may be required for certain operations.

				
Ear Protection	Safety Footwear	Head Protection	Safewty Gloves	
				
Eye Protection	Protective Clothing	Dust / Allergens Protection	Hi Viz Jacket	Caution Floor Sign

NOTE: A risk assessment should be conducted to determine which PPE should be worn.

WEEE Legislation (Waste, Electrical and Electronic Equipment)



Vacuum cleaner, accessories and packaging should be sorted for environmentally - friendly recycling.

(Only for EU Countries)Do not dispose of vacuum cleaner into household waste! According to the European Directive 2012/19/EU on waste electrical and electronic equipment and its incorporation into national law.

Vacuum cleaners that are no longer suitable for use must be separately collected and sent for recovery in an environmentally - friendly manner.

Failure to rectify the problem or in the event of a breakdown contact your Numatic dealer or the Numatic Technical helpline +44 (0)1460 269268

Daily

Keep the machine clean, including hoses and tubes.
Ensure the bag and filter are fitted.
Regularly examine the power cord.
Check dust bag frequently.
Check filters are clean.

Weekly - as daily and:-

Check for any worn or damaged parts and replace immediately.
Do not steam clean or pressure wash.

Safety Critical Components

Mains leads:

HO5-V2V2-F 12.5 x 2 Core x 1.00 mm^2

GB

Information for DRY use Vacuum cleaners

WARNING!

Read the instruction manual before using the machine.

Operators shall be adequately instructed on the use of their machine.
As with all electrical equipment, care and attention must be exercised at all times during use, in addition to ensuring that routine and preventative maintenance is carried out periodically to ensure safe operation.
Failure to carry out maintenance as necessary, including the replacement of parts to the correct standard could render this equipment unsafe and the manufacturer can accept no responsibility in this respect. Maintenance should only be carried out by a qualified person.
This machine is for DRY USE only and must not be stored outside or used in wet conditions.
The machine shall be disconnected from the mains by removing the plug from the supply socket during cleaning or maintenance and when replacing parts or converting the machine to another function.
The machine is not to be used by children or persons with reduced physical, sensory or mental capabilities, or lack of experience or knowledge, unless they have been given supervision or instruction.
This appliance is intended to be cleaned and maintained by an adult.
Children being supervised are not to play with the machine.
This machine is not a toy.

CAUTION

This machine is not suitable for picking up hazardous or explosive dust.
Contact your local distributor if you require a machine capable of performing these tasks.
Ensure that the filtration system fitted to the machine is suitable for the material being collected.
This vacuum cleaner is intended for indoor use in the collection of dry materials.
This machine should be stored indoors only.

NOTES

This machine is intended for commercial dry use, for cleaning onboard aircraft only.
This product complies with the requirements of clause 20 of IEC/EN 60335-2-69 Stability and Mechanical Hazards.
This vacuum cleaner is fitted with a thermal protection device. If the vacuum cleaner stops working, remove the plug from the wall before investigating where the fault lies.
If the vacuum cleaner has a blockage, switch off, remove the plug from the socket, inspect the floor tool, tubes and hose for debris. If the floor tool, tubes and hose are clear, replace the dust bag and clean the filter.
The vacuum cleaner should be inspected after use for damage.
Not suitable for the collection of biological hazards, hazardous, or explosive dusts .
The vacuum cleaner should be stored in a dry place.

DO

- Keep your machine clean including hoses and tubes.
- Change dust bag frequently.
- Keep filters clean.
- Keep diffuser filter (where fitted) clean.
- Use filter bags, they will enhance performance and help keep machine clean.
- Use a Numatic Original filter bag under fine dust conditions.
- Keep hoses and tubes clear.
- Replace any worn or damaged parts immediately.
- Only use the socket outlet on the machine for purposes specified in the instructions.
- Only use the brushes provided with the machine. The use of other brushes may impair safety.
- Regularly examine the power cord. If damage is found such as cracking or ageing the power cord must be replaced by a qualified person.
- Only replace the power cord with the correct Numatic approved replacement part.

DO NOT

- Pull on the cable to unplug the machine from the power supply.
- Use to suck up hot ashes or lighted cigarette ends.
- Use steam cleaners or pressure washers to clean the machine or use in the rain.
- Immerse in water for cleaning.
- Attempt machine maintenance or cleaning unless the power supply plug has been removed from the supply outlet.
- Do not use in wet environments or to collect wet materials.